

1. Doc. Control

| Boot Loader Revision | Purpose of Modifications | Compiler Version | Date |
|----------------------|--------------------------|------------------|------------|
| Rev. 1.0.0 | First release | - | 10/02/2006 |

2. Features

- **CAN Protocol**
 - CAN used as Physical Layer
 - 7 re-programmable ISP CAN identifiers
 - Auto-bitrate
- **In-System Programming**
 - Read/Write Flash and EEPROM memories
 - Read Device ID
 - Full chip Erase
 - Read/Write configuration bytes
 - Security setting from ISP command
 - Remote application start command

3. Description

This document describes the “**Slim**” **CAN boot loader** functionality as well as its protocol to efficiently perform operations on the on chip Flash & EEPROM memories.

This boot loader implements the “In-System Programming” (ISP). The ISP allows the user to program or re-program the microcontroller on-chip Flash & EEPROM memories without removing the device from the system and without the need of a pre-programmed application.

The CAN boot loader can manage a communication with an host through the CAN network. It can also access and perform requested operations on the on-chip Flash & EEPROM memories.



AT90CAN128
AT90CAN64
AT90CAN32

“Slim”
CAN
Boot Loader

4. Boot Loader Environment

The **CAN AT90CAN128/64/32 boot loader** is loaded in the “Boot Loader Flash Section” of the on-chip Flash memory. The boot loader size is less than 4K bytes, so the physical “Boot Loader Flash Section” only is half-full. The application program size must be lower or equal the “Application Flash Section” plus 4K bytes(c.f. [Table 4-1 “Device Memory Mapping \(byte addressing\)” on page 2](#)).

Table 4-1. Device Memory Mapping (byte addressing)


| Memory | | AT90CAN128 | AT90CAN64 | AT90CAN32 |
|--------------------------------------|-------------------------------|-------------------|-------------------|-------------------|
| FLASH | Size | 128 K bytes | 64 K bytes | 32 K bytes |
| | Add. Range | 0x00000 - 0x1FFFF | 0x00000 - 0x0FFFF | 0x00000 - 0x07FFF |
| “Application Flash Section” | Size | 120 K bytes | 56 K bytes | 24 K bytes |
| | Add. Range | 0x00000 - 0x1DFFF | 0x00000 - 0xDFFF | 0x00000 - 0x05FFF |
| “Boot Loader Flash Section” | Size | 8 K bytes | | |
| | Add. Range | 0x1E000 - 0x1FFFF | 0x0E000 - 0x0FFFF | 0x06000 - 0x07FFF |
| “Boot Loader Reset Addresses” (1) | Small (1 st) Boot | 0x1FC00 | 0x0FC00 | 0x07C00 |
| | Second Boot | 0x1F800 | 0x0F800 | 0x07800 |
| | Third Boot (2) | 0x1F000 | 0x0F000 | 0x07000 |
| | Large (4 th) Boot | 0x1E000 | 0x0E000 | 0x06000 |
| EEPROM | Size | 4 K bytes | 2 K bytes | 1 K bytes |
| | Add. Range | 0x0000 - 0x0FFF | 0x0000 - 0x07FF | 0x0000 - 0x03FF |

Note: 1. The “Boot Loader Reset Address” depends on the fuse bits “BOOTSZ”. Refer to the datasheet for more details on Flash memories (Flash, EEPROM, ...) behaviors.
2. “Slim” CAN Boot Loader reset address.

4.1 Physical Environment

A generic bootloader deals with the host (or PC) through a CAN interface. The generic bootloader is a service able to be connected to other interfaces (LIN, RS232, SPI, TWI, ...).


Figure 4-1. Physical Environment



4.2 Boot Loader Description

4.2.1 Overview

Figure 4-2. Boot Loader Diagram



4.2.2 Entry Point


Only **one** "Entry Point" is available, it is the entry point to the boot loader. The "BOOTRST" fuse of the device have to be set. After Reset, the "Program Counter" of the device is set to "Boot Reset Address" (c.f. [Table 4-1 "Device Memory Mapping \(byte addressing\)"](#) on page 2). This "Entry Point" initializes the "boot process" of the boot loader.

4.2.3 Boot Process

The “*boot process*” of the boot loader allows to start the application or the boot loader itself. This depends on two variables:

- The “**Hardware Condition**”.
The Hardware Condition is defined by a device input PIN and its activation level (Ex: INT0/PIND.0, active low). This is set in “config.h” file.
- The “**Boot Status Byte**”.
The Boot Status Byte “**BSB**” belongs to the “Boot Loader Configuration Memory” (c.f. [Section 5.4.4.1 “Boot Status Byte - “BSB””](#) on page 9). Its default value is 0xFF. An ISP command allows to change its value.

Figure 4-3. Boot Process Diagram




4.2.4 Protocol Identification

The “*Protocol Identification*” of the boot loader select what protocol to use, CAN or other protocol. A polling of the physical lines is done to detect an activity on the media. These lines are:

- **PORT_CAN_RX**: The polling is be done on RXCAN/PIND.6.
- (no other interface).

A low level on **PORT_CAN_RX** line starts the initialization of the CAN peripheral.

Figure 4-4. Protocol Identification Diagram



4.2.5 CAN Initialization

The CAN, used to communicate with the host, has the following configuration:

- **Standard:** CAN format 2.0A (11-bit identifier).
- **Frame:** Data frame.
- **Bitrate:** Depends on Extra Byte - "EB" (see "Extra Byte - "EB"" on page 10):
 - "EB" = 0xFFH: Use the software auto-bitrate.
 - "EB" != 0xFFH: Use CANBT[1..3] bytes to set the CAN bitrate (see "CANBT[1..3] - "BTC[1..3]"," on page 10).

The initialization process must be performed after each device Reset. The host initiates the communication by sending a data frame to select a node. In case of auto-bitrate, this will help the boot loader to find the CAN bitrate. The CAN standard says that a frame having an acknowledge error is re-sent automatically. This feature and the capability of the CAN peripheral to be set in "LISTEN" mode are used by the auto-bitrate. Once the synchronization frame is received without any error, a recessive level is applied on the acknowledge slot by releasing the "LISTEN" mode.

The software auto-bitrate supports a wide range of baud rates according with the system clock (CKIO) set on the device (c.f. "FOSC" definition in "config.h" file). This functionality is not guaranteed on a CAN network with several CAN nodes.

4.2.6 CAN Protocol Overview

The "CAN Protocol" is an higher level protocol over serial line (CAN Bus).

It is described in specific paragraphs in this document (See "CAN Protocol & ISP Commands" on page 12.).

4.2.7 ISP Commands Overview

The "CAN Protocol" decodes "ISP commands". The set of "ISP commands" obviously is independent of any protocol.

It is described in a specific paragraph in this document (See "CAN Protocol & ISP Commands" on page 12.).

4.2.8 Output From Boot Loader

The output from the boot loader is performs after receiving the ISP command: "Start Application" (See "CAN Protocol & ISP Commands" on page 12.).

5. Memory Space Definition

The boot loader supports up to five (5) separate memory spaces. Each of them receives a code number (value to report in the corresponding protocol field) because low level access protocols (drivers) can be different.

The access to memory spaces is a byte access (i.e. the given addresses are byte addresses).

Table 5-1. Memory Space Code Numbers

| Space ⁽¹⁾ | Code Number | Access |
|---------------------------------|-------------|--------------|
| Flash Memory | 0 | Read & Write |
| EEPROM Data Memory | 1 | Read & Write |
| - | 2 | - |
| Boot Loader Information | 3 | Read only |
| Boot Loader Configuration | 4 | Read & Write |
| Device registers ⁽²⁾ | 5 | Read only |
| Signature | 6 | Read only |

Note: 1. Sometimes, the discriminating is not physical (ex: "Signature" is a sub-set of the code of the boot loader Flash Section" as well as "Boot Loader Information").
2. New.

5.1 Flash Memory Space

The Flash memory space managed by the boot loader is a sub-set of the device Flash. It is the "Application Flash Section".

Table 5-2. Flash Memory Space (Code Number 0)

| Flash Memory Space | AT90CAN128 | AT90CAN64 | AT90CAN32 |
|----------------------------------|-------------------|------------------|-------------------|
| Size | 124 K bytes | 60 K bytes | 28 K bytes |
| Address Range | 0x00000 - 0x1EFFF | 0x00000 - 0xEFFF | 0x00000 - 0x06FFF |
| Number of page(s) ⁽¹⁾ | 2 | 1 | 1 |

Note: 1. Page parameter is different in the boot loader and in the device itself.

5.1.1 Reading or Programming

The "ISP Read" or "ISP Program" commands only access to Flash memory space in byte addressing mode into a page of 64K bytes (c.f. [Table 5-2 "Flash Memory Space \(Code Number 0\)" on page 6](#)). Specific ISP commands allows to select the different pages.

The boot loader will return a "Device protection" error if the Software Security Byte "SSB" is set while read or write command occurs (c.f. [Section 5.4.4.2 "Software Security Byte - "SSB" on page 9](#)).

5.1.2 Erasing

The "ISP Erase" command is a full erase (all bytes=0xFF) of the Flash memory space. This operation is available whatever the Software Security Byte "SSB" setting. A the end of the operation, the Software Security Byte "SSB" is reset to level 0 of security ([Section 5.4.4.2 "Software Security Byte - "SSB" on page 9](#)).

5.1.3 Limits

The ISP commands on the Flash memory space has no effect on the boot loader (no effect on “*Boot Loader Flash Section*”).

The sizes of the Flash memory space (code number 0) for ISP commands are given in [Table 5-2 “Flash Memory Space \(Code Number 0\)” on page 6](#).

5.2 EEPROM Data Memory

The EEPROM data memory space managed by the boot loader is the device EEPROM.

Table 5-3. EEPROM Data Memory Space (Code Number 1)

| EEPROM Data Memory Space | AT90CAN128 | AT90CAN64 | AT90CAN32 |
|--------------------------|-----------------|-----------------|-----------------|
| Size | 4 K bytes | 2 K bytes | 1 K bytes |
| Address Range | 0x0000 - 0x0FFF | 0x0000 - 0x07FF | 0x0000 - 0x03FF |
| Number of page(s) | -- No paging -- | | |

5.2.1 Reading or Programming

The EEPROM data memory space is used as non-volatile data memory. The “*ISP Read*” or “*ISP Program*” commands access byte by byte to this space (no paging).

The boot loader will return a “*Device protection*” error if the Software Security Byte “**SSB**” is set while read or write command occurs (c.f. [Section 5.4.4.2 “Software Security Byte - “SSB”” on page 9](#)).

5.2.2 Erasing

The “*ISP Erase*” command is a full erase (all bytes=0xFF) of the EEPROM Data Memory space. This operation is available whatever only if the Software Security Byte “**SSB**” is reset ([Section 5.4.4.2 “Software Security Byte - “SSB”” on page 9](#)).

5.2.3 Limits

The sizes of the EEPROM Data Memory space (code number 1) for ISP commands are given in [Table 5-3 “EEPROM Data Memory Space \(Code Number 1\)” on page 7](#).

5.3 Boot Loader Information

The Boot loader information space managed by the boot loader is included the code of the boot loader. It is in the “*Boot Loader Flash Section*”.

Table 5-4. Boot Loader Information Space (Code Number 3)

| Signature Space | | AT90CAN128 | AT90CAN64 | AT90CAN32 |
|---------------------|---------------------------|-----------------|-----------|-----------|
| Bootloader Revision | Address: 0x00 (Read only) | ≥ 0x01 | | |
| Boot ID1 | Address: 0x01 (Read only) | 0xD1 | | |
| Boot ID2 | Address: 0x02 (Read only) | 0xD2 | | |
| Number of page(s) | | -- No paging -- | | |

5.3.1 Reading or Programming

The “*ISP Read*” command accesses byte by byte to this space (no paging).

No access protection is provided on this read only space.

5.3.2 Erasing

Not applicable for this read only space.

5.3.3 Limits

Details on the Boot loader information space (code number 3) for ISP commands are given in [Table 5-4 "Boot Loader Information Space \(Code Number 3\)" on page 7.](#)

5.3.4 Boot Loader Information Byte Description

5.3.4.1 Boot Revision

Boot Revision: Read only address = 0x00, value \geq 0x01.

5.3.4.2 Boot ID1 & ID2

Boot ID1 & ID2: Read only addresses = 0x01 & 0x02, value = 0xD1 & 0xD2.

5.4 Boot Loader Configuration

The Boot loader configuration space managed by the boot loader is included in the "*Boot Loader Flash Section*".

Table 5-5. Boot Loader Configuration Space (Code Number 4)

| Signature Space | | | AT90CAN128 | AT90CAN64 | AT90CAN32 |
|-----------------------------|--------|------------|-------------------------------------|-----------|-----------|
| Boot Status Byte | "BSB" | Add.: 0x00 | (default value=0xFF) | | |
| Software Security Byte | "SSB" | Add.: 0x01 | (default value=0xFF) | | |
| Extra Byte | "EB" | Add.: 0x02 | (default value=0xFF) ⁽¹⁾ | | |
| CANBT1 | "BTC1" | Add.: 0x03 | (default value=0xFF) ⁽²⁾ | | |
| CANBT2 | "BTC2" | Add.: 0x04 | (default value=0xFF) ⁽²⁾ | | |
| CANBT3 | "BTC3" | Add.: 0x05 | (default value=0xFF) ⁽²⁾ | | |
| Node Number | "NNB" | Add.: 0x06 | (default value=0xFF) ⁽³⁾ | | |
| CAN Re-locatable ID Segment | "CRIS" | Add.: 0x07 | (default value=0x00) | | |
| Start Address Low | "SA_L" | Add.: 0x08 | (default value=0x00) | | |
| Start Address High | "SA_H" | Add.: 0x09 | (default value=0x00) | | |
| Number of page(s) | | | -- No paging -- | | |

Note: 1. See "Extra Byte - "EB"" on page 10. for validity.
 2. See "CANBT[1..3] - "BTC[1..3]"," on page 10. for validity.
 3. See "(CAN) Node Number - "NNB"" on page 10. for validity.

5.4.1 Reading or Programming

The "*ISP Read*" command accesses byte by byte to this space (no paging).

Access protection is only provided on the Software Security Byte (c.f. [Section 5.4.4.2 "Software Security Byte - "SSB"" on page 9.](#)

5.4.2 Erasing

The "*ISP Erase*" command is **not available** for this space.

5.4.3 Limits

Details on the Boot loader configuration space (code number 6) for ISP commands are given in [Table 5-5 "Boot Loader Configuration Space \(Code Number 4\)" on page 8.](#)

5.4.4 Boot Loader Configuration Byte Description

5.4.4.1 Boot Status Byte - "BSB"

The Boot Status Byte of the boot loader is used in the "boot process" ([Section 4.2.3 "Boot Process" on page 4](#)) to control the starting of the application or the boot loader. If no Hardware Condition is set, the default value (0xFF) of the Boot Status Byte will force the boot loader to start. Else (Boot Status Byte != 0xFF & no Hardware Condition) the application will start.

5.4.4.2 Software Security Byte - "SSB"

The boot loader has the Software Security Byte "SSB" to protect itself and the application from user access or ISP access. It protects the Flash and EEPROM memory spaces and itself.

The "ISP Program" command on Software Security Byte "SSB" can only write an higher priority level. There are three levels of security:

Table 5-6. Security levels

| Level | Security | "SSB" | Comment |
|-------|----------------|--------|--|
| 0 | NO_SECURITY | 0xFF | - This is the default level. - Only level 1 or level 2 can be written over level 0. |
| 1 | WR_SECURITY | 0xFE | - In level 1, it is impossible to write in the Flash and EEPROM memory spaces. - The boot loader returns an error message. - Only level 2 can be written over level 0. |
| 2 | RD_WR_SECURITY | ≤ 0xFC | - All read and write accesses to/from the Flash and EEPROM memory spaces are not allowed. - The boot loader returns an error message. - Only an "ISP Erase" command on the Flash memory space resets (level 0) the Software Security Byte. |

The table below gives the authorized actions regarding the SSB level.

Table 5-7. Allowed actions regarding the Software Security Byte "SSB"

| ISP Command | NO_SECURITY | WR_SECURITY | RD_WR_SECURITY |
|--|-------------|---------------------|----------------|
| Erase Flash memory space | Allow | Allow | Allow |
| Erase EEPROM memory space | Allow | - | - |
| Write Flash memory space | Allow | - | - |
| Write EEPROM memory space | Allow | - | - |
| Read Flash memory space | Allow | Allow | - |
| Read EEPROM memory space | Allow | Allow | - |
| Write byte(s) in Boot loader configuration (except for "SSB") | Allow | - | - |
| Read byte(s) in Boot loader configuration | Allow | Allow | Allow |
| Write "SSB" | Allow | only a higher level | - |

| ISP Command | NO_SECURITY | WR_SECURITY | RD_WR_SECURITY |
|-------------------------------------|-------------|-------------|----------------|
| Read Boot loader information | Allow | Allow | Allow |
| Read Signature | Allow | Allow | Allow |
| Blank check (any memory) | Allow | Allow | Allow |
| Changing of memory space | Allow | Allow | Allow |

5.4.4.3 Extra Byte - “EB”

The Extra Byte is used to switch the CAN Initialization to auto-bitrate or to fixed CAN bit timing.

- “EB” = 0xFFH: Use the software auto-bitrate.
- “EB” != 0xFFH: Use CANBT[1..3] bytes of Boot loader configuration space to set the CAN bit timing registers of the CAN peripheral (no auto-bitrate).

Note: Not yet exploited. This will be done in a future boot loader version.

5.4.4.4 CANBT[1..3] - “BTC[1..3]“

When “EB” != 0xFFH, CANBT[1..3] bytes of Boot loader configuration space are used to set the CAN bit timing registers of the CAN peripheral.(no auto-bitrate).

An other way to write these byte is described in [Section 5.6.4.1 “CANBT\[1..3\] Registers.” on page 11.](#)

Note: Not yet exploited. This will be done in a future boot loader version.

5.4.4.5 (CAN) Node Number - “NNB”

[See “CAN Protocol & ISP Commands” on page 12.](#)

Note: Not yet exploited. This will be done in a future boot loader version.

5.4.4.6 CAN Re-locatable ID Segment - “CRIS”

[See “CAN Protocol & ISP Commands” on page 12.](#)

5.4.4.7 Start (application) Adress High & Low- “SA_H” & “SA_L”

[See “CAN Protocol & ISP Commands” on page 12.](#)

5.5 Signature

The Signature space managed by the boot loader is included the code of the boot loader. It is in the “*Boot Loader Flash Section*”.

Table 5-8. Signature Space (Code Number 6)

| Signature Space | | AT90CAN128 | AT90CAN64 | AT90CAN32 |
|-------------------|---------------------------|-----------------|-----------|-----------|
| Manufacturer Code | Address: 0x00 (Read only) | 0x1E | | |
| Family Code | Address: 0x01 (Read only) | 0x81 | | |
| Product Name | Address: 0x02 (Read only) | 0x97 | 0x96 | 0x95 |
| Product Revision | Address: 0x03 (Read only) | ≥ 0x00 | ≥ 0x00 | ≥ 0x00 |
| Number of page(s) | | -- No paging -- | | |

5.5.1 Reading or Programming

The “ISP Read” command accesses byte by byte to this space (no paging).

No access protection is provided on this read only space.

5.5.2 Erasing

Not applicable for read only space.

5.5.3 Limits

Details on the Signature space (code number 6) for ISP commands are given in [Table 5-8 "Signature Space \(Code Number 6\)"](#) on page 10.

5.6 Device Registers

The device registers space managed by the boot loader is the 64 I/O registers and the 160 Ext. I/O registers of the device. They are accessed by the equivalent assembler instruction:

LDS Rxx, REG_ADD

where **REG_ADD** is in the address range 0x20 (**PINA**) up to 0xFA (**CANMSG**).

5.6.1 Reading or Programming

The "*ISP Read*" command accesses byte by byte to this space (no paging).

No access protection is provided on this read only space.

5.6.2 Erasing

Not applicable for this read only space.

5.6.3 Limits

This space is not bit addressing and an unimplemented register returns 0xFF.

5.6.4 Device Registers Description

c.f. appropriate data sheet for information.

5.6.4.1 *CANBT[1..3] Registers.*

If they are read before to disable the auto-bitrate (when "**EB**" = 0xFFH), in the same time they they are copied into "**BTC1**", "**BTC2**" & "**BTC3**" of the Boot loader configuration space (see "[CANBT\[1..3\] - "BTC\[1..3\]"](#)", on page 10).

6. CAN Protocol & ISP Commands

This section describes the higher level protocol over the CAN network communication and the coding of the associated ISP commands.


6.1 CAN Frame Description

The CAN protocol only supports the CAN standard frame (c.f. ISO 11898 for high speed and ISO 11519-2 for low speed) also known as CAN 2.0 A with 11-bit identifier.

A message in the CAN standard frame format begins with the "Start Of Frame (SOF)", this is followed by the "Arbitration field" which consist of the identifier and the "Remote Transmission Request (RTR)" bit used to distinguish between the data frame and the data request frame called remote frame. The following "Control field" contains the "IDentifier Extension (IDE)" bit and the "Data Length Code (DLC)" used to indicate the number of following data bytes in the "Data field". In a remote frame, the DLC contains the number of requested data bytes. The "Data field" that follows can hold up to 8 data bytes. The frame integrity is guaranteed by the following "Cyclic Redundant Check (CRC)" sum. The "ACKnowledge (ACK) field" compromises the ACK slot and the ACK delimiter. The bit in the ACK slot is sent as a recessive bit and is overwritten as a dominant bit by the receivers which have at this time received the data correctly.

The ISP CAN protocol only uses CAN standard data frame.

Figure 6-1. CAN Standard Data Frame



To describe the ISP CAN protocol, a symbolic name is used for Identifier, but default values are given within the following presentation.

Table 6-1. Template for ISP CAN command

| Identifier 11 bits | Length 4 bits | Data[0] 1 byte | ... | Data[n-1] 1 byte | Description |
|----------------------------------|------------------|-------------------|-----|---------------------|---------------------|
| SYMBOLIC_NAME ("CRIS"<<4) + X | n (<=8) | Value or meaning | | | Command description |

Because in a point-to-point connection, the transmit CAN message is repeated until a hardware acknowledge is done by the receiver.

The boot loader can acknowledge an incoming CAN frame only if a configuration is found.

This functionality is not guaranteed on a network with several CAN nodes.

6.2 CAN ISP Command Data Stream Protocol

6.2.1 CAN ISP Command Description

Several CAN message identifiers are defined to manage this protocol.


Table 6-2. Defined CAN Message Identifiers for CAN ISP Protocol

| Identifier | ISP Command Detail | Value |
|--------------------|--|-------------------|
| ID_SELECT_NODE | Open/Close a communication with a node | ("CRIS" << 4) + 0 |
| ID_PROG_START | Start Memory space programming | ("CRIS" << 4) + 1 |
| ID_PROG_DATA | Data for Memory space programming | ("CRIS" << 4) + 2 |
| ID_DISPLAY_DATA | Read data from Memory space | ("CRIS" << 4) + 3 |
| ID_START_APPLI | Start application | ("CRIS" << 4) + 4 |
| ID_SELECT_MEM_PAGE | Selection of Memory space or page | ("CRIS" << 4) + 6 |
| ID_ERROR | Error message from boot loader only | |

It is possible to allocate a new value for CAN ISP identifiers by writing the "CRIS" byte with the base value for the group of identifier.

The maximum "CRIS" value is 0x7F and its the default value is 0x00.

Figure 6-2. Remapping of CAN Message Identifiers for CAN ISP Protocol



6.2.2 Communication Initialization

The communication with a device (CAN node) must be opened prior to initiate any ISP communication. To open communication with the device, the Host sends a "Connecting" CAN message ("ID_SELECT_NODE") with the node number "NMB" passed as parameter. If the node number

passed is 0xFF then the CAN boot loader accepts the communication (Figure 6-3). Otherwise the node number passed in parameter must be equal to the local "NNB" (Figure 6-4).

Figure 6-3. CAN Boot Loader First Connection





Figure 6-4. CAN Boot Loader Network Connection



Before opening a new communication with another device, the current device communication must be closed with its connecting CAN message ("ID_SELECT_NODE").

6.3 CAN ISP Commands

6.3.1 CAN Node Select

A CAN node must be first **opened** at the beginning and then **closed** at the end of the session.

6.3.1.1 CAN Node Select Requests from Host

Table 6-3. CAN Node Select Requests from Host

| Identifier | L | Data[0] | Description |
|------------------------------------|---|---------------------|--|
| ID_SELECT_NODE (("CRIS"<<4)+ 0) | 1 | Node Number ("NNB") | Open or close communication with a specific node |

6.3.1.2 CAN Node Select Answers from Boot Loader

Table 6-4. CAN Node Select Answers from Boot Loader

| Identifier | L | Data[0] | Data[1] | Description |
|------------------------------------|---|---------------------------|---------|-----------------------------|
| ID_SELECT_NODE (("CRIS"<<4)+ 0) | 2 | "Boot Loader Revision" | 0x00 | Communication closed |
| | | | 0x01 | Communication opened |

6.3.2 Changing Memory / Page

To change of memory space and/or of page, there is only one command, the switch is made by "Data[0]" of the CAN frame.

6.3.2.1 Changing Memory / Page Requests from Host

Table 6-5. Changing Memory / Page Requests from Host

| Identifier | L | Data[0] | Data[1] | Data[2] | Description |
|--|---|---------|-----------------|---------|----------------------------|
| ID_SELECT_MEM_PAGE (("CRIS"<<4)+ 6) | 3 | 0x00 | Memory space | Page | No action |
| | | 0x01 | | | Select Memory space |
| | | 0x02 | | | Select Page |
| | | 0x03 | | | Select Memory space & Page |

6.3.2.2 Changing Memory / Page Answers from Boot Loader

Table 6-6. Changing Memory / Page Answers from Boot Loader

| Identifier | L | Data[0] | Description |
|--|---|---------|---|
| ID_SELECT_MEM_PAGE (("CRIS"<<4)+ 6) | 1 | 0x00 | Selection OK (even if "Data[0]"=0 in the request frame) |

6.3.3 Reading / Blank Checking Memory

These operations can be executed only with a device previously open in communication. This command is available on the memory space and on the page previously defined.

To start the reading or blank checking operation, the Host sends a CAN message (“ID_DISPLAY_DATA”) with the operation required in Data[0], the start address and end address are passed as parameters.

6.3.3.1 Reading / Blank Checking Memory Requests from Host

Table 6-7. Reading / Blank Checking Memory Requests from Host

| Identifier | L | Data[0] | Data[1] | Data[2] | Data[3] | Data[4] | Description |
|-------------------------------------|---|---------|-----------------------------|---------|---------------------------|---------|---|
| ID_DISPLAY_DATA (("CRIS"<<4)+ 3) | 5 | 0x00 | Start Address (MSB, LSB) | | End Address (MSB, LSB) | | Display data of selected Memory space / Page |
| | | 0x80 | | | | | Blank check on selected Memory space / Page |

6.3.3.2 Reading / Blank Checking Memory Answers from Boot Loader

Table 6-8. Reading / Blank Checking Memory Answers from Boot Loader

| Identifier | L | Data[0] | Data[1] | ... | Data[7] | Description |
|-------------------------------------|---------|-------------------------|---------|-----|---------|---|
| ID_DISPLAY_DATA (("CRIS"<<4)+ 3) | up to 8 | Up to 8 Data Bytes | | | | Data Read |
| | 0 | - | - | - | - | Blank check OK |
| | 2 | First not blank address | | - | - | Error on Blank check |
| ID_ERROR (("CRIS"<<4)+ 6) | 1 | 0x00 | - | - | - | Error Software Security Set ("Display data" only) |

6.3.4 Programming / Erasing Memory

These operations can be executed only with a device previously open in communication. They need two steps:

- The first step is to indicate address range for program or erase command.
- The second step is to transmit the data for programming only.

To start the programming operation, the Host sends a “start programming” CAN message (ID_PROG_START) with the operation required in “Data[0]”, the start address and the end address are passed as parameters.

6.3.4.1 Programming / Erasing Memory Requests from Host

Table 6-9. Unit. Programming / Erasing Memory Requests from Host

| Identifier | L | Data[0] | Data[1] | Data[2] | Data[3] | Data[4] | Data[5..7] | Description |
|-----------------------------------|---|----------------------|-----------------------------|---------|---------------------------|---------|------------|---|
| ID_PROG_START (("CRIS"<<4)+ 1) | 5 | 0x00 | Start Address (MSB, LSB) | | End Address (MSB, LSB) | | - | Init. prog. the selected Memory space / Page |
| | 3 | 0x80 | 0xFF | 0xFF | - | - | - | Erase the selected Memory space / Page |
| ID_PROG_DATA (("CRIS"<<4)+ 2) | n | data[0..(n-1)] (n≤8) | | | | | | Data to program |

6.3.4.2 Programming / Erasing Memory Answers from Boot Loader

Table 6-10. Programming / Erasing Memory Answers from Boot Loader


| Identifier | L | Data[0] | Description |
|-----------------------------------|---|---------|---|
| ID_PROG_START (("CRIS"<<4)+ 1) | 0 | - | Command OK |
| ID_PROG_DATA (("CRIS"<<4)+ 2) | 1 | 0x00 | Command OK and end of transfer |
| | | 0x02 | Command OK but new (other) data expected |
| ID_ERROR (("CRIS"<<4)+ 6) | 1 | 0x00 | Error - Software Security Set (" <i>Init. program</i> " only) |

6.3.4.3 Programming Memory Examples

Table 6-11. Programming Memory Examples

| Request/ Answer | CAN Message (hexadecimal) | | | Description |
|---|---------------------------|---|-------------------------|-------------------------------|
| | Identifier | L | Data[..70] | |
| R (>>) | 000 | 1 | FF | CAN Node Select |
| A (<<) | 000 | 2 | 01 01 | Communication opened |
| Default Memory space = Flash, default Page = page_0 | | | | |
| R (>>) | 001 | 5 | 00 00 02 00 12 | Prog. Add 0x0002 up to 0x0012 |
| A (<<) | 001 | 0 | 0 | Command OK |
| R (>>) | 002 | 8 | 01 02 03 04 05 06 07 08 | 1 st Data transfer |
| A (<<) | 002 | 1 | 02 | Command OK, new data expected |
| R (>>) | 002 | 8 | 11 12 13 14 15 16 17 18 | 2 nd Data transfer |
| A (<<) | 002 | 1 | 02 | Command OK, new data expected |
| R (>>) | 002 | 1 | 20 | 3 rd Data transfer |
| A (<<) | 002 | 1 | 00 | Command OK, end of transfer |

Figure 6-5. Result of the Above Programming Memory Example ⁽¹⁾



Note: 1. AVR Studio Program Memory representation

6.3.5 Starting Application

This operation can be executed only with a device previously open in communication.

To start the application, the host sends a start application CAN message with the “way of” selected in “Data[1]”. The application can be start by a watchdog reset or by jumping to an word address (in the Flash memory) given by SA_H & SA_L of Boot Loader Configuration Space.

No answer is returned by the boot loader.

Table 6-12. Start application Requests from Host

| Identifier | L | Data[0] | Data[1] | Data[2] | Data[3] | Description |
|------------------------------------|---|---------|---------|---------|---------|---------------------------------------|
| ID_START_APPLI ((“CRIS”<<4)+ 4) | 2 | 0x03 | 0x00 | - | - | Start application with watchdog reset |
| | 4 | | 0x80 | 0x00 | 0x00 | Jump to address (SA_H : SA_L) |

7. Appendix A: #define in "config.h" file

7.1 Processor Definitions

```
// Global
#define AVR
#define AT90CAN128 1
#define AT90CAN64 2
#define AT90CAN32 3

// Hardware condition (for boot or application start)
// INT on DVK90CAN1 board = INT0 or PD.0 - active low with pull-up
#define PIN_HWCBC PIND_Bit0
#define PORT_HWCBC PORTD_Bit0
#define LEVEL_HWCBC 0 // active at "0" or "1"
#define PULLUP_HWCBC 1 // pull-up "ON"="1", "OFF"="0"
/* // Center Key on DVK90CAN1 board = PE.2 active low with pull-up
#define PIN_HWCBC PINE_Bit2
#define PORT_HWCBC PORTE_Bit2
#define LEVEL_HWCBC 0 // active at "0" or "1"
#define PULLUP_HWCBC 1 // pull-up "ON"="1", "OFF"="0" */
// Application
#define USE_DEVICE AT90CAN128
#define USE_UART1
#define FOSC 8000

// Switches for Specific definitions
#ifndef USE_DEVICE
# error You must define USE_DEVICE AT90CAN128, AT90CAN64 or AT90CAN32 first in
"config.h" file
# elif USE_DEVICE == AT90CAN128
# define MANUF_ID 0x1E // ATMEL
# define FAMILY_CODE 0x97 // 128 Kbytes of Flash
# define PRODUCT_NAME 0x81 // AT90CAN family
# define PRODUCT_REV 0x00 // rev 0
# define FLASH_SIZE 0x1FFFF // in bytes
# define FLASH_PAGE_SIZE 0x100 // in bytes
# define BOOT_SIZE 0x2000 // in bytes
# define EEPROM_SIZE 0x1000 // in bytes
# elif USE_DEVICE == AT90CAN64
# define MANUF_ID 0x1E // ATMEL
# define FAMILY_CODE 0x96 // 64 Kbytes of Flash
# define PRODUCT_NAME 0x81 // AT90CAN family
# define PRODUCT_REV 0x00 // rev 0
# define FLASH_SIZE 0x0FFFF // in bytes
# define FLASH_PAGE_SIZE 0x100 // in bytes
# define BOOT_SIZE 0x2000 // in bytes
# define EEPROM_SIZE 0x0800 // in bytes
# elif USE_DEVICE == AT90CAN32
# define MANUF_ID 0x1E // ATMEL
# define FAMILY_CODE 0x95 // 32 Kbytes of Flash
# define PRODUCT_NAME 0x81 // AT90CAN family
# define PRODUCT_REV 0x00 // rev 0
# define FLASH_SIZE 0x07FFF // in bytes
# define FLASH_PAGE_SIZE 0x100 // in bytes
# define BOOT_SIZE 0x2000 // in bytes
# define EEPROM_SIZE 0x0400 // in bytes
# else
# error USE_DEVICE definition is not referenced in "config.h" file
#endif

#ifndef USE_UART1
# ifndef USE_UART2
# error You must define either USE_UART1 or USE_UART2 in
"config.h" file
# endif
#endif

// Polling pins definition
#ifdef USE_UART1
# define PIN_UART_RX PINE_Bit0 // for UART0
```

```
# define PORT_UART_TX     PORTE_Bit1      // for UART0
#endif
#ifndef USE_UART2
# define PIN_UART_RX     PIND_Bit2       // for UART1
# define PORT_UART_TX     PORTD_Bit3     // for UART1
#endif

#define PIN_CAN_RX       PIND_Bit6
#define PORT_CAN_TX     PORTD_Bit5
```

7.2 UART Definitions

```
//----- UART LIB CONFIGURATION -----
#define UART_AUTOBAUD_EXTERNAL_DETECTION
#define UART_MINIMUM
#define BDR_GENERATOR BRG_TIMER1
#define BAUDRATE     AUTOBAUD
//#define BAUDRATE     19200
#define test_hit()   uart_test_hit()
#define _getkey()    uart_getchar()
#define putchar      uart_putchar
```

7.3 Boot Loader Definitions

```
//----- BOOTLOADER CONFIGURATION -----
// Uart protocol
#define PROTOCOL_DATA           64
#define GLOBAL_BUFFER_SIZE     PROTOCOL_DATA+4
#define NB_BYTE_MAX_FOR_DISPLAY_COMMAND 64
#define HEX_SIZE_DISP_PAGE     16

#define USE_RCS_HEX_PROTOCOL
#define USE_RCS_CAN_PROTOCOL

//----- Bootloader identification definition ----
#define BOOT_VERSION    0x01 // @00 // Ver 01: JT-18.10.05
#define BOOT_ID1        0xD1 // @01
#define BOOT_ID2        0xD2 // @02

#define MAX_OFFSET_ID   0x7F0

#define NO_SECURITY     0xFF
#define RD_WR_SECURITY  0xFC
#define BSB_DEFAULT     0xFF
#define SSB_DEFAULT     0xFF
#define EB_DEFAULT      0xFF
#define NNB_DEFAULT     0xFF
#define CRIS_DEFAULT    0xFF // if (offset_id_copy>MAX_OFFSET_ID) offset_id_copy=0;
#define BTC1_DEFAULT    0xFF
#define BTC2_DEFAULT    0xFF
#define BTC3_DEFAULT    0xFF

#define SSB_RD_PROTECTION 0xFC
#define SSB_WR_PROTECTION 0xFE
```

7.4 Memory Definitions

```
//----- Memory Definition -----
#define MEM_USER         0
#define MEM_CODE         0
#define MEM_FLASH       0
#define MEM_EEPROM      1
#define MEM_CUSTOM      2
#define MEM_BOOT        3 // Boot information
#define MEM_XAF         4 // Boot configuration
#define MEM_SIGNATURE    6

#define MEM_DEFAULT     MEM_FLASH

#define PAGE_DEFAULT    0x00
```

8. Appendix B: CAN Protocol Summary

Table 8-1. CAN Protocol Summary - Requests from Host

| ISP Command Request Identifier | L | Data [0] | Data [1] | Data [2] | Data [3] | Data [4] | Data [5] | Data [6] | Data [7] | Description |
|--|---|----------------------|---------------|----------|-------------|----------|----------|----------|----------|-------------------------------|
| ID_SELECT_NODE (("CRIS"<<4)+ 0) | 1 | Node | - | - | - | - | - | - | - | Open or close communication |
| ID_PROG_START (("CRIS"<<4)+ 1) | 5 | 0x00 | Start Address | | End Address | | - | - | - | Initialization of programming |
| | 3 | 0x80 | 0xFF | 0xFF | - | - | - | - | - | Erasing |
| ID_PROG_DATA (("CRIS"<<4)+ 2) | n | data[0..(n-1)] (n≤8) | | | | | | | | Data to program |
| ID_DISPLAY_DATA (("CRIS"<<4)+ 3) | 5 | 0x00 | Start Address | | End Address | | - | - | - | Display (read) data |
| | | 0x80 | | | | | - | - | - | Blank check |
| ID_START_APPLI (("CRIS"<<4)+ 4) | 2 | 0x03 | 0x00 | - | - | - | - | - | - | Start Application with reset |
| | 4 | | 0x01 | 0x0000 | | - | - | - | - | Start Application jump add. 0 |
| ID_SELECT_MEM_PAGE (("CRIS"<<4)+ 6) | 3 | Memory space | Page | 0x00 | - | - | - | - | - | No action |
| | | | | 0x01 | - | - | - | - | - | Select Memory space |
| | | | | 0x02 | - | - | - | - | - | Select Page |
| | | | | 0x03 | - | - | - | - | - | Select Memory space & Page |

Table 8-2. CAN Protocol Summary - Answers from Boot Loader

| ISP Command Answer Identifier | L | Data [0] | Data [1] | Data [2] | Data [3] | Data [4] | Data [5] | Data [6] | Data [7] | Description |
|---|---|--------------------------------|----------|----------|----------|----------|----------|----------|----------|---|
| ID_SELECT_NODE (("CRIS"<<4)+ 0) | 2 | Boot loader revision | 0x00 | - | - | - | - | - | - | Communication closed |
| | | | 0x01 | - | - | - | - | - | - | Communication opened |
| ID_PROG_START (("CRIS"<<4)+ 1) | 0 | - | - | - | - | - | - | - | - | Command OK |
| ID_PROG_DATA (("CRIS"<<4)+ 2) | 1 | 0x00 | - | - | - | - | - | - | - | Cmd. OK & end of transfer |
| | | 0x02 | - | - | - | - | - | - | - | Cmd. OK & new data expected |
| ID_DISPLAY_DATA (("CRIS"<<4)+ 3) | n | data[0..(n-1)] (n≤8) | | | | | | | | Data Read |
| | 0 | - | - | - | - | - | - | - | - | Blank check OK |
| | 2 | 1 st Failed Address | | - | - | - | - | - | - | Error on Blank check |
| ID_SELECT_MEM_PAGE or ID_ERROR (("CRIS"<<4)+ 6) | 1 | 0x00 | - | - | - | - | - | - | - | Selection OK or Error Software Security Set |